




MelGeek Mojo68三模机械键盘 使用手册

拨动开关



键盘可在三种连接模式内相互切换, 拨动开关如图示由左到右分别为蓝牙、有线、2.4G

- 2.4G模式需搭配附送接收端使用

指示灯



蓝牙模式配对与切换



- 1 拨动开关到蓝牙模式
- 2 同时按住BT+数字(左图所示)至左下指示灯蓝灯闪烁, 开启蓝牙配对模式。
- 3 通过想要连接键盘的设备搜索“MelGeek”并连接。
- 4 本键盘蓝牙模式可支持连接八个设备, 并通过如下组合键切换:
短按BT+1键切换蓝牙设备1
短按BT+2键切换蓝牙设备2
短按BT+3键切换蓝牙设备3
短按BT+4键切换蓝牙设备4
短按BT+5键切换蓝牙设备5
短按BT+6键切换蓝牙设备6
短按BT+7键切换蓝牙设备7
短按BT+8键切换蓝牙设备8
长按BT+数字可以抹掉对应数字设备的配对记录。

FN键组合功能




同时按住FN加对应按键组合实现相应图示键位功能



MelGeek Mojo68 Keyboard Manual (Tri-mode Version)



Mode Switch




The keyboard has three working modes, from left to right, it is Bluetooth, wired and 2.4G

- 2.4G mode should be used with the attached receiver

Indicator Light




CAPS LOCK




BATTERY


(The red light flashes when the battery is low)



BLUETOOTH




WIRED




2.4G

Bluetooth Mode Pairing And Switching




- 1 Switch to Bluetooth mode
- 2 Short press **BT**+Numbers to activate Bluetooth pairing, the indicator flashes blue.
- 3 Search Bluetooth device “MelGeek” on your device.
- 4 The keyboard support pairing up to 8 devices
Short press **BT**+1 to switch to Bluetooth 1
Short press **BT**+2 to switch to Bluetooth 2
Short press **BT**+3 to switch to Bluetooth 3
Short press **BT**+4 to switch to Bluetooth 4
Short press **BT**+5 to switch to Bluetooth 5
Short press **BT**+6 to switch to Bluetooth 6
Short press **BT**+7 to switch to Bluetooth 7
Short press **BT**+8 to switch to Bluetooth 8
Long press **BT**+Numbers to erase pairing record.



Blue light flashing in Bluetooth pairing mode
Blue light on when Bluetooth is connected

Instruction for using FN key



Press combination key “**FN**+1/2/3/4/5/6/7/8/9/0/-/=” to switch **F1~F12**